




## PROBLEM STATEMENT

**Need**: A product that can detect an accident and notify emergency services to decrease response times

- The median response time for an ambulance to the scene of a motor vehicle crash (MVC) is 9 minutes and increases in rural areas (National Library of Medicine)
- After 12 minutes, the mortality rate of MVC's double compared to a 7 minute response time (NEJM)
- 42% of all motorcycle accidents are single-vehicle crashes(Dolman Law Group)
- Reducing the median response time to 7 minutes could prevent 13% of MVC fatalities (NEJM)


## SOLUTION


A modification to a motorcycle helmet that can detect accidents and alert first responders as fast as possible



## **OUR DESIGN**








#### **Primary Goals:**

- Use an Arduino Nano to transmit data to an app
- Use the data to detect accidents
- Contact the emergency contacts after an accident

#### **Secondary Goals:**

- Aesthetically pleasing and easy to use app
- ☐ Add relevant extra features such as weather (as time allows)




## INTENDED USERS

- Primary: Motorcyclists
  - Mountain Bikers
  - ☐ Long Distance Cyclists
- Designed to help protect
  - solo riders
  - Remote areas
  - Night traveling

## INTENDED USES

- Report a possible crash when no else is around to see
- Set an emergency contact
- → View local weather data
- View a Trip History







## **OUR DESIGN APPROACH**

#### **APP**

- Create a Flutter app that:
  - Stores contacts
  - Sends message via Twilio
- Add extra
  features and
  color scheme

#### **ARDUINO**

- Create a basic skeleton with all data containers
- Add packages for all sensors on Arduino
- Add BLE codethat transmitsdata to app

## CONCERNS AND LIMITATIONS


#### **CONCERNS**


- Error inTransmittingdata via BLE
- Error when sending messages via Twilio
- General StateErrors in App


#### **LIMITATIONS**


- No true BLE connection, use manufacturer data
- Simple crash detection algorithm


## **APP LAYOUT**













## COMPONENTS

- Arduino Nano BLE Sense

  33 rev 2
- 3.7 Volt Battery
- Micro-Lipo BatteryCharger
- ☐ 3.3 Volt Buck Converter
- Slide Switch



#### <u>Arduino Nano Sense 33 rev 2 -</u>

arduino nano with a BLE module and multiple sensors



Battery - 3.7 Volts

- 1200 milliamp hours



<u>Charger</u> - 500 milliamp per

hour charger and battery

output




<u>Converter</u> - takes in the 3.7

volt output from the battery

and converts it to 3.3 V



## HARDWARE PICTURE



# SOFTWARE DETAILS

Programming Language: Dart

Framework: Flutter

Messaging API: Twilio

Arduino Firmware: C++









## **FLUTTER**

#### Apps Built With Flutter:

- 🔲 BMW
- Google Pay
- Google Classroom
- Toyota Infotainment Systems
- PubG Mobile





#### <u>Flutter Framework</u>

- A framework intended for creating applications
- Develop cross platformapplications for iOS,Android, macOS, Windows,Linux
- ☐ Written in Dart
- Compiles in native binary

## FLUTTER LIBRARIES





- Flutter Reactive BLE flutter library used to
  communicate with arduino
  via BLE
- Hive local NoSQL database used to store emergency contacts and weather data
- ☐ Weather library used to get weather data from Open Weather API
- Provider library used to manage state using class models

## **TWILIO**

#### Flutter Implementation

```
1 vimport 'package:flutter/material.dart';
    import 'package:twilio flutter/twilio flutter.dart';
4 ∨ class TwilloController {
     static final TwilioFlutter twilioFlutter = TwilioFlutter(
          accountSid: 'AC03a114d524e9cec2bb660edeb01bbf61', // Account SID
          authToken: '1b2ab9b8d914086b68d106283e1e74cd', // Auth Token
          twilioNumber: '+18888361535'); //Twilio Number
      bool hasSent = false;
      TwilloController();
      bool sendMessage() {
       if (! hasSent)
          twilioFlutter.sendSMS(
              toNumber: '+16305364344',
              messageBody: 'EMERGENCY: possible crash detected');
          print("send command");
          hasSent = true;
          else {
          return false:
       return true;
      //Use sendSMS with the recipient number and message body.
      //priavte variable hasCalled (false if function hasnt been called yet)
      //(set true once called)
      //send sms }
```

#### TWILIO - Messaging API

- Can be used to
  - Send and Receive SMS text messages
  - ☐ Send and Receive calls
- Free trial account includes
  Account SID, Authentication
  Token, and phone number

#### **Twilio CLI Formatting**

```
twilio api:core:messages:create \
    --from +15017122661 \
    --body "Hi there" \
    --to +15558675310
```